

**GENERALSCAN**

**GS M52**  
**MOBILE COMPUTER**  
**QUICK USER GUIDE**



**EN**

## INTRODUCTION

Thank you for choosing our Generalscan GS M52 Mobile Computer.

This guide gives you the information you will need to operate GS M52 Mobile Computer. If there are any further questions, please contact [support@generalscan.cloud](mailto:support@generalscan.cloud).

## COPYRIGHT

**GENERALSCAN** trademarks are registered in many countries around the world. Generalscan Inc, and/or its subsidiaries, all rights reserved.

This manual contains proprietary information of Generalscan. It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the expressed written permission of Generalscan.


All specifications and signs in this guide are subject to change without notice.

All software without licenses shall not be transferred to others.

## BATTERY SAFETY


- Do not immerse or expose to water or other liquids, or expose to fire, explosion, or other hazard.
- Do not disassemble or open, crush, bend or deform, puncture, or shred.
- Do not short circuit a battery or allow metallic or conductive objects to contact the battery terminals.
- Do not use the battery if it is bulging, deformed or damaged.
- To charge the mobile device battery, the battery and charger temperatures must be between +32 °F and +104 °F (0 °C and +40 °C).
- Do not use batteries other than those provided by GENERALSCAN, otherwise we will not be responsible for the consequences.
- Dispose of batteries according to instructions.
- Please follow local regulations to promptly dispose of used rechargeable batteries.

## UNPACKING




- ① GS M52 × 1 ② Protective Case × 1 ③ USB Type-C Cable × 1  
④ Quick user guide × 1

## MULTI-ANGLE APPEARANCE




## FEATURES



**Fn** key can switch numbers, uppercase letters, lowercase letters and function keys. You can reference detailed status according to changes on the up right corner.


**Up** and **down** direction keys can adjust volume after **Fn** key switched to function keys.



## ■ INSTALLING THE SIM CARD

### INSTALLING THE SIM CARD

Press the metal contact down with paper clip until the SIM card slot forced out. Pull out the SIM card slot and put the SIM card into it. Then push the slot back to its position.



## POWER ON AND POWER OFF

### Power on

Press the Power button for about 3 seconds to turn it on.

### Power off

Press the Power button for about 3 seconds until the menu displays, then tap Power off.

### Restart

When the GS M52 doesn't work, or system crash, press the power button about 10 seconds to force it to restart.

### Setting

Scanning parameters can be set by ScanSettings APP; Advanced settings can be set by AdvanceSettings APP. Password "654321" needs to be typed-in at the first time use after starting up.




## CHARGING

Please ensure no water inside or outside the charging connector before charging.

Plug the USB-Type C cable into the charging interface.

Use the adapter providing 5V DC power.



## LED INDICATORS AND AUDIO PROMPT

<b>Charging</b>	Red LED Being on
<b>Charging 100%</b>	Green LED Being on
<b>Bluetooth pairing successfully</b>	Beep
<b>Decode successfully</b>	Beep / Green LED Being on



### **Warranty Information**

For Generalscan products warranty information, please visit [www.generalscan.cloud/warranty](http://www.generalscan.cloud/warranty)



### **Service Information**

If there is any problem of Generalscan products, please visit [www.generalscan.cloud/services](http://www.generalscan.cloud/services)

## **GENERALSCAN**

QUICK USER GUIDE

**FOR GS M52**

Email: [Support@generalscan.cloud](mailto:Support@generalscan.cloud)

©GENERALSCAN All rights reserved.

Version 1.0



886783009801